

DOOR SWING / HANDING

DOOR/FRAME SWING/HANDING PRACTICE

When viewed from the exterior side of the door, the hinge edge of the door determines the hand. When the hinge edge is at the left, the swing is left hand, if the door swings away from the viewer; left hand reverse if it swings toward the viewer. When the hinge edge is at the right, the swing is right hand if the door swings away from the viewer; right hand reverse if it swings toward the viewer.

